


Please Note: Steps 1 and 2 below must be completed for EACH Mesh Node.

1 Connect




- Connect the Mesh Node to the Clean Router as illustrated.
- Power on the Mesh Node.
- Watch lights on the front of the Mesh Node.

2 Wait for Setup to Complete

- Lights flashing 1, 2, 3, 4 in sequence indicates setup has started.
- Alternating flashing of lights 1 and 4 indicate that setup is complete.
- After setup is complete unplug the Mesh Node and move it to another location.
- One minute after powering on the Mesh Node verify that light 2 is solid on - NOT flashing.*

* If light 2 is flashing then the Mesh Node may need to be moved closer to another node.



3 Get Help (optional)




<https://CleanRouter.com/support>
 Support@CleanRouter.com



Call: (520) 445-4673
 Open 6am to 8pm MST
 Monday - Friday
 9am to 5pm MST
 Saturday

Please Note: Steps 1 and 2 below must be completed for EACH Mesh Node.

1 Connect




- Connect the Mesh Node to the Clean Router as illustrated.
- Power on the Mesh Node.
- Watch lights on the front of the Mesh Node.

2 Wait for Setup to Complete

- Lights flashing 1, 2, 3, 4 in sequence indicates setup has started.
- Alternating flashing of lights 1 and 4 indicate that setup is complete.
- After setup is complete unplug the Mesh Node and move it to another location.
- One minute after powering on the Mesh Node verify that light 2 is solid on - NOT flashing.*

* If light 2 is flashing then the Mesh Node may need to be moved closer to another node.



3 Get Help (optional)



<https://CleanRouter.com/support>
 Support@CleanRouter.com



Call: (520) 445-4673
 Open 6am to 8pm MST
 Monday - Friday
 9am to 5pm MST
 Saturday